

600\*100mm 白底无边框


04 INSTALLATION INSTRUCTIONS

Introduction to the Installation Steps for VOV Ventilation Units (If unclear, contact our installation team)Installation instructions are as follows:


1.Install the main unit, ensuring at least 22cm of clearance space above the ceiling.




2.Measure the required installation space and cut an opening in the ceiling.



3.Create an exhaust vent leading outdoors.



4.Install the outdoor weather cap and connect the flexible duct.



5. Secure the main unit to the ceiling joists, then connect the ductwork and power supply.



6. After installing the main unit begin ceiling restoration.



7. A carpenter applies putty with a brush to finish ceiling repair.



8. Install filters and air vents to complete the installation.



05 AFTER-SALES SERVICE

5.1 WARRANTY POLICY

Implementing the Three Guarantees Policy (repair/replacement/refund) as follows:

- ① 7-Day Fault Resolution

Within 7 days of delivery confirmation, VOV provides free repair, replacement, or refund for non-human-caused performance failures through authorized service centers.
- ② 7-Day No-Reason Return (Online Exclusive)

Applies solely to VOV official website purchases. Exclusions: Human-induced damage  
Broken packaging  
Missing accessories  
Shipping fees for returns shall be borne by the customer.
- ③ Service Timelines & Coverage

Refunds: Processed within 7 days of receiving returned goods  
Exchanges: Available within 30 days  
Warranty:  
» Full unit: 1 year  
» Major components: 3 years  
Proof of purchase (delivery receipt/invoice) required for all claims.

5.2 WARRANTY CARD

Submitting this warranty card enables faster processing of your service requests. Before completing, contact us to confirm eligibility for your specific needs.

FIRST REPAIR RECORD	Customer Name	Contact Info
<div></div>	<div></div>	<div></div>
Product Model	Purchase Date	Repair Date
<div></div>	<div></div>	<div></div>
Original Serial No.	Fault Description	Resolution
<div></div>	<div></div>	<div></div>

5.3 WARRANTY EXCLUSIONS

VOV shall not provide warranty services if: Expired Coverage  
1.The product exceeds the Three Guarantees Policy validity period.Unauthorized Modifications  
2.Damage caused by:Repairs performed by non-VOV authorized personnel Misuse, impact, negligence, or abuse Liquid ingress, accidents, or unauthorized alterations Disassembly or tampering with serial labels/anti-counterfeit marks.  
3.Force Majeure Events Damage resulting from uncontrollable external factors (e.g., natural disasters).  
4.Improper Handling Failure to follow usage, maintenance, or storage guidelines in the product manual.  
5.Invalid Proof Discrepancy between the Three Guarantees certificate and product model, or evidence of tampering.

5.4 PRODUCT INFORMATION

GB4706.1-2005,GB4706.27-2008, GB4343.1-2003,GB17625.1-2003  
Compliance Standards  
GB4706.1-2005 · GB4706.27-2008 · GB4343.1-2003 · GB17625.1-2003  
(China National Safety & EMC Standards for Household Appliances)

Product Certification

Model Airs7

Serial Number: See product barcode label

Inspection Result


Certified Compliance

Inspector ID

PASS 09



Frameless Smart Ventilation Unit  
AirS7



User Manual

Please read this manual carefully before use and retain properly for future reference.

CONTENTS

01	Important Precautions	
02	Product Introduction	2.1 Technical Specifications 2.2 App Features 2.3 App Network Configuration
03	Filter Guide	3.1 Filter Specifications 3.2 Cleaning & Maintenance 3.3 Replacement Guidelines
04	Installation Manual	
05	After-Sales Service	5.1 Warranty Policy 5.2 Warranty Registration 5.3 Non-Warranty Cases 5.4 Product Registration

01 IMPORTANT PRECAUTIONS

- ⚠️ WARNINGS


  - 1. Do not modify or repair this product yourself.
  - 2. Voltage Restriction: Use ONLY 110-220V. Incorrect voltage may cause fire, electric shock, or damage.
  - 3. Power Cord Safety: Avoid excessive bending/pulling; Damaged cords may cause fire.
  - 4. Liquid Hazard: Never expose the unit to rain or liquids.
- ⚠️ NOTES

  - 1. Securely mount the unit to prevent falling.
  - 2. Avoid impacts/drops to prevent damage.


02 PRODUCT INTRODUCTION

2.1 Technical Specifications

Product Name	AirS7	Housing Material	Gypsum
Rated Voltage	24V DC	Net Weight	6.3kg
Power Input	36W	Noise Level	28 dB(A)



2.2 APP Function Introduction



🔘 Power On/Off

🔘 When turned ON, the machine enters Smart Fan Speed Mode at Level 1. TVOC detection starts simultaneously. After TVOC preheating completes normally, the fan speed level adjusts automatically based on the detected TVOC value.

🌀 Fan Speed

Press the Level 1 Speed button to set the fan to Level 1. Pressing any other button exits this mode.  
Press the Level 2 Speed button to set the fan to Level 2. Pressing any other button exits this mode.  
Press the Level 3 Speed button to set the fan to Level 3. Pressing any other button exits this mode.

🧠 Smart Mode


Pressing the Smart Mode button sets the fan speed display to Level 1 (🟡). The fan speed level and the breathing light color will then change dynamically based on the detected TVOC value.  
PM2.5 ≤ 50: Fan speed = Level 1; Breathing light = White.  
PM2.5 51-100: Fan speed = Level 2; Breathing light = White.  
PM2.5 ≥ 101: Fan speed = Level 3; Breathing light = Yellow.

03 Filter Introduction

3.1 Detailed Filter Introduction

HEPA Layer:

Utilizes a HEPA filter, effectively filtering harmful particles such as pollen, dust mite debris, and fibers in the air, comprehensively preventing secondary pollution.



3.2 Filter Cleaning, Maintenance & Care

- Cleaning & Maintenance:

Before cleaning or maintenance, disconnect the power supply. For stubborn stains or dust, wipe with a damp cloth soaked in warm water.⋯
- Filter Care:

Unplug the appliance before removing the filter; Depending on air quality, it is recommended to remove the filter every 1-2 months. Use a hairdryer (cool setting) or vacuum cleaner to clean dust and other pollutants adsorbed by the filter. Then, air-dry the filter in sunlight for approximately 2 hours to maintain its optimal purification efficiency.

3.3 Filter Precautions & Replacement

- Important Notes

  - ① Handling  
Always power off and unplug the unit before moving.
  - ② Installation  
Filters must be correctly seated in designated slots. Maintain ≥ 20cm clearance between air intake and walls/obstructions.
  - ③ Operation  
IMMEDIATELY STOP USE if any of these occur: Unusual noises/smells; Overheating or Erratic fan rotation  
**NEVER:**
    - Insert fingers/objects into vents
    - Place hair/fabric near vents (entanglement risk)
    - Sit on, lean against, or tilt the unitEnsure ventilation when used near combustion devices to prevent carbon monoxide poisoning.

- ④ Usage Restrictions & Filter Maintenance  
Prohibited Environments: NEVER OPERATE in the following conditions to prevent electric shock, fire, or damage: Unstable surfaces (prone to tipping), High-temperature/humid areas (e.g., bathrooms), Water-exposed locations

Request replacements via authorized dealers or our company directly.

During use, due to the different usage environments, the service life of the filter screen varies. When the machine reminds you to replace the filter screen, please do so as soon as possible to ensure the purification efficiency of the air exchanger. It is recommended to contact the company or local agent to replace the filter screen. Do not discard the used filter screen anywhere.⋯